



APPROVED BY
HEIROL
PEOPLE

USE & CARE OF HEIROL MANDOLINE SLICER

item 40230



SETUP:

Unfold the legs until they click into place. Set the mandoline on a solid surface. Push and turn the adjustment knob to the desired setting. You can choose to slice at a thickness of 1mm to 9mm or to cut julienne strips of 4.5mm or 9mm.



SLIDE:

Lift the top of the food holder to expose the prongs on the underside, and slide the end of the vegetable onto the prongs to secure it. Use the food holder to firmly slide the vegetable from the top to the bottom of the runway. Continue a back-and-forth motion keeping the food holder in contact with the runway until the vegetable is completely sliced. CAUTION: Blades are extremely sharp. Wearing safety gloves is recommended.



CLEAN:

With one hand, lift the stainless steel plate. With your other hand, turn the dial to 3mm and carefully remove the cylinder. Wash using warm, soapy water. Use the cleaning brush for the blades. The finger protector is top-rack dishwasher safe. Once completely dry, attach the blade guard and store it for future use.



APPROVED BY
HEIROL
PEOPLE

HEIROL MANDOLIINIIN
KÄYTTÖ JA HOITO
tuote 40230



VALMISTELU:

Avaa mandoliinin jalat kunnes ne naksahtavat paikalleen. Aseta laite tasaiselle alustalle. Valitse haluamasi leikkausasetus painamalla ja pyörittämällä sivussa sijaitsevaa säätöruuvia. Voit valita siivusi paksuudeksi 1-9 mm tai voit viipaloita Julienne-tyylisesti 4.5 tai 9 mm paksuudella.



KÄYTTÖ:

Nosta sormisuojan kansi jotta paljastat sen alla olevat piikit, ja aseta pilkottava vihannes piikkeihin kiinni. Ota tukeva ote sormisuojusta ja liu'uta vihannesta kohti terää ylhäältä alaspäin. Jatka liikettä edestakaisin, sormisuoja visusti kiinni laudassa, kunnes vihannes on täysin viipaloitu. HUOMIO: Terät ovat erittäin teräviä. Suojahanskojen käyttöä suositellaan.



PUHDISTUS:

Nosta ruostumaton teräslevy ylös toisella kädellä, ja toisella kädellä käännä säätöruuvi 3 mm -asetukseen ja varovasti nosta tela pois mandoliinista. Pese lämpimällä vedellä ja käytä saippuaa. Käytä tiskiharjaa terien puhdistukseen. Sormisuoja on turvallista pestä pesukoneen ylätelineessä. Kun laite on täysin kuiva, aseta terä takaisin mandoliiniin ja laita säilytykseen seuraava käyttöä varten.